

CBF500 Hugger

Fitting Instructions

Fitting kit contents

- 1 x hugger
- 2 x m6 x 12mm Allen bolts
- 2 x plastic washers

Fitting Instructions.

1. Remove the brake pipe guide p-clip from the swing arm, leaving it attached to the brake line. (pic 1)
2. Loosen the 2 left hand side foot rest hanger bolts and remove the top bolt. (pic 2)
3. Lower the hanger to gain access to the front chain guard bolt.
4. Remove the chain guard retaining bolts and take off the chain guard.
5. Take the Pyramid hugger and feed it in from the left hand side over the wheel
6. Offer up the chain guard side to the chain guard mount brackets and loosely attach 2 m6 x 16mm countersunk bolts and washers.
7. Using the lug locate p-clip into front of the 2 holes on the right hand side of the hugger, then fasten through the rear hole.
8. Tighten the chain guard side bolts
9. There will be some play in the holes so if needed a better fit can be achieved by loosening the bolts, positioning the hugger by pulling the relevant side and re-tightening the bolts while being held in required position.
10. Reattach the footrest hanger making sure all the bolts are fully tightened.

