

MT-07 Hugger 2014 onwards

Fitting Kit: not required

Instructions:

1. Remove the existing chainguard/hugger. (It may be necessary to remove the foot peg heel plate on the chainguard side) On the exhaust can side, two plastic push rivets need to be removed. This can be done with a long Allen key or a bent piece of rigid wire.
1. Remove the bolt holding the brake hose clip and slide the clip out of the way.
1. Feed the hugger over the tyre and into position, making sure that the mounting tab on the break hose side is fed under the break hose.
1. Fix both mountings on the chainguard side using the original bolts (do not tighten fully).
1. Then position the break hose clip over the mounting tab of the hugger and fix using the original bolt (do not tighten fully)
1. Check the alignment of the hugger and adjust if necessary. Then tighten all fixing points fully.
1. Re-fit the foot peg heel plate if it has been removed.
1. Re-check the alignment of the hugger and ensure that **all fixings are checked periodically.**