



### Important Fitting Procedure

Fit Handguard as per handguard fitting instructions.

Loosely assemble the clamp to the handlebar as per diagram.

### The clamp bolts must be tightened in the following order:

**Tighten bolt (6)** through the handguard to the clamp connector (2) of the clamp assembly.

**Tighten bolt (3)** to solidly lock the clamp connector (2) between the clamp saddles (1).

**Tighten bolt (4)** to secure the clamp assembly firmly to the handlebar.

**Note:** The clamp is designed to allow the nut on bolt (3) to pull into the recessed hole. This eliminates the need for a wrench after the bolt starts to tighten.

